

The Auto-Linking Feature

Step Operation

- 1 Put the Power Module into SETUP Mode by quickly clicking its button 5 times. The Module's Status LED will be quickly blinking green. NOTE: SETUP Mode times out in 5 minutes.
- 2 Put all of the other devices you are "linking" into their SETUP Mode by quickly clicking their buttons 5 times in a row. Each device's Status LED will be quickly blinking green. NOTE: The Vacuum Hose is put into SETUP Mode by plugging it in and quickly craddling its 3-position switch to the right (II) and back to center 5 times in a row.
- 3 Now click the Power Module's button 3 more times in a row and it will communicate with all the devices which are in SETUP Mode and teach them the Network ID. The Power Module will then take all of the devices out of SETUP Mode.
- 4 Test the vacuum system components for proper communication by turning the vacuum unit on/off with each component.